



PARTS IDENTIFICATION



CONTROL PANEL



Rot (Rotate the image)

Frz (Freeze the image)

Neg (Display film negatives)

Text (Switch between image/text mode)

Save (Save captured images)

Title (Freeze the top 1/8 of the screen)

Split (Split Image function)

Mem (Multiple Screen Display, the stored images will be displayed in a 4 x 4 matrix)

Ppw (Control the projector On/Standby)

Pin (Projector input signal selection)


↑/↓ (Move the image up/down)

POWER (Control the visualizer On/Off)

CAM/PC1/PC2 (CAM/RGB input signal selection)


RS232 cable. Some projector models may require a converter cable in addition to this standard RS232 cable to connect to the projector control port, for the pin locations and shape of some projectors' control port connector may be different from the connector of a standard RS232 cable. Once the visualizer is connected to the projector, you can control the projector's power on, standby and input selection by using the visualizer. (Aside from Hitachi projectors, the Code Writing program that comes with the visualizer is required to access this function.)

Step 3: Connect to a desktop computer.




Note: You can connect a laptop computer to the RGB IN port of side panel using a RGB cable.

Step 4: Connect to the HD equipment with HDMI input.




Step 5: Connect to the video equipment with Video input.



In the step 2, the connection between the C-Video output signals to the projector was established, where the RGB cable runs from the visualizer and goes to the projector. Once the connections have been made as detailed in the steps 2,3,4,5, input signals from the HD equipment, computer, visualizer camera, and C-Video are going to the RGB1 input on the projector and will be displayed on the projector screen as RGB1. These signals can be seen in turn when pressing “CAM/ PC1/PC2” and “HDMI/VIDEO” on the control panel of the visualizer.

Step 6: Connections for external control from the computer.



Use the computer RS232 cable (9-pin to 9-pin) to make the connections displayed below to control the visualizer from an external computer. A USB connection enables the computer to capture still images and/or video streams from the visualizer. Special software is required for this operation.

4. Turn on the power by pressing the “POWER” button.

PAL/NTSC VIDEO OUTPUTS


The S-Video and composite video outputs are set to PAL (NTSC) during manufacturing.

WORKING ON THE STAGE

1. Place your material on the platform.
2. Select the enlargement required using the “⊕T” and “W⊖” buttons.
3. Adjust the focus using the “Near” and “Far” buttons or “AUTO” button.


WORKING OUTSIDE THE STAGE

To show a 3-dimensional object using the visualizer, place the object on the working surface and adjust the “⊕T” or “W⊖” and “AUTO” keys. If the object is too large for the stage or if you would like to show it from one of its side, or a different angle, just place the object behind or in front of the unit and manually tilt the camera head (remove the close-up lens prior to titling the camera head).




LIGHT

The arm lights are powered on when the power is turned on. Each time you press the “LAMP” button, the lighting changes occur as demonstrated.




ADJUSTING IMAGE SIZE

To reduce or enlarge the image size displayed on the screen, press the “**T**” (Zoom in) or “**W**” (Zoom out) button.



WORKING WITH NEGATIVES

The visualizer is automatically set to display normal materials on the screen when the power is on. To display negatives, turn on the backlight by pressing the “LAMP” key, and then press the “Neg” button to display the film negatives. Press the “Neg” button again to display normal materials in the color mode.



FOCUSING

When the visualizer is turned on the focus automatically adjusts to the stage, Only 3D objects require a focus adjustment.

Press the “AUTO” button to auto focus.

Press the “FAR” or “NEAR” button to focus manually.

FREEZING IMAGE

To show a still image on the screen, when the output signal is RGB, press the “Frz” button. The frozen image cannot be adjusted (Zoom in/out, color adjustment, etc.).

BRIGHTNESS ADJUSTMENT

If the image effect is not satisfactory, you can adjust the brightness to get a better image effect. Use the “BRIGHT +” or “BRIGHT -” button to adjust the brightness. To increase the brightness, press the “BRIGHT +” button. To decrease it, press the “BRIGHT -” button.

WHITE BALANCE ADJUSTMENT

Each time the lighting condition changes, the user should adjust the white balance of the camera.

Press the “AUTO” button to adjust the white balance automatically.

AUTO ADJUSTMENT

One of the visualizer’s special functions is auto adjustment. Press the “AUTO” button to auto adjust the white balance and the focus.

TEXT/IMAGE MODE

Press the “Text” button to switch between image/text modes. To display a text file, switch to the text mode to get a clearer text effect.

COLOR AND B&W MODE SWITCH

Press “B&W” once to enter the Black & White mode; press a gain to return to the Color mode. (On the remote control)

HDMI/VIDEO INPUTS

Press the “HDMI/ VIDEO” button to switch between HDMI and composite video signals.

RGB INPUTS

Use the “CAM/PC1/PC2” button to switch between Camera and different RGB signals. Each time the “CAM/PC1/PC2” button is pressed, it provides seamless transitions among different sources such as Camera, COMPUTER (IN), and RGB (IN).

Notes: RGB OUT always outputs RGB IN signals.

PROJECTOR ON/STANDBY

Press the “POWER” button to turn on the visualizer’s power and press the “Ppw” button to turn the projector power on. To place the projector on standby after the use, press the “Ppw” button and hold for more than 2 seconds. (Using the remote control, press the “PROJECTOR POWER” button)

PROJECTOR INPUTS SELECTION

When the projector is connected to several input sources, use the “Pin” button to switch between projector signal inputs. (Using the remote control, press the “PROJECTOR INPUT” button)

IMAGE ROTATION

In order to rotate the image, press the “Rot” button once, the displayed image will be rotated clockwise. Continue to press the “Rot” button to restore the image to its initial position.

IMAGE REVERSION







To display a vertically mirrored image, press the “MIRROR” button. Press the “MIRROR” button again to exit.


INFRARED REMOTE CONTROL






The visualizer’s remote control can control the camera from different angles. On the left side of the visualizer stage, there is a built-in remote control storage compartment where you can store the remote control when it is not in use.

Please note that an infrared remote control can only be used up to a certain distance to the unit. Objects situated between the visualizer and the infrared remote control and a weak battery may interfere with the reception.

4 X 4 MULTIPLE SCREEN DISPLAY


Press “Mem”, the stored first sixteen images can be displayed in a 4 x 4 matrix. Use , , ,  button to Select the image that you want to display, then click  button to display the selected image, press 

button to delete the selected image. Press  to exit the 4 x 4 image display mode.

On the remote control, the “RECALL”, “”, “”, “”, “”, “” and “TEXT” button can do the operation. Press “EXIT” to exit the 4 x 4 image display mode.

INSTALLING VISUALIZER SOFTWARE

This function is to snap and display images with the USB interface, which includes displaying static and dynamic pictures, snapping dynamic images and playback the dynamic images with the Windows Media Player or its own player.

- A. Insert the CD-ROM that comes with the visualizer into the CD-ROM drive. If Autorun is enabled on your system, then the Software Setup window will be displayed automatically as below.
If it does not start automatically, after inserting the CD-ROM, Click [Start] → [My Computer], and double click  (the CD-ROM drive letter might be different in different computer systems), and then the above screen will appear immediately.
- B. Click the **Install Capture Program** button to install the program that captures images in the MP4 or JPG format.
- C. Click the **Install Code-Writing Program** button to install Code-Writing Program.
- D. After the installation is finished, then click the **Exit** button to exit the Software Setup window.
- E. Shut down your computer when prompted in order for the changes to take effect.
- F. Use the USB2.0 cable provided to connect your computer to the visualizer before your computer is restarted.

USB PORT

The USB port can be used to store still images from the visualizer in a computer. Connect the visualizer to your computer with the supplied USB cable. The visualizer software is available on the supplied CD-ROM.

*** Please pay attention to the following:**

1. Computer hardware requirement: 1.8 GHz Intel(R) Core Duo processor, 2GB RAM, Independent display card with 1GB of Video RAM, USB 2.0 port, Hard disk 40G or more, Monitor display resolution higher than XGA (1024x768, 16bit high color or above).
2. Operating system: Windows XP/Vista/windows 7/Windows 8.
3. Must use a high-speed USB 2.0 cable provided.
4. When connecting the visualizer to a desktop computer with the high-speed USB 2.0 cable provided, we recommend using the USB port located on the rear of the mainframe. The USB port on the front of the computer might have interference.

USB IMAGE CAPTURE

You can capture images on the visualizer from a computer connected with a USB connector. You can also save the contents with image-capture and video-recording functions. The Software Manual in the CD-ROM will tell you how to do these.

E. Note:

Do not connect / disconnect the USB cable when the application is running, which will cause the program to be interrupted.

CONTROLLING VISUALIZER BY COMPUTER

You can control the visualizer from a computer connected with a RS232 connector.


- A. Connect the computer and the visualizer using the RS232 cable.
- B. Double click X:\232 Control\Control Panel (you can open this file from the CD and double click it, or copy this file to any directory on your computer's hard drive and double click to launch it).


CONTROLLING PROJECTOR BY VISUALIZER

The code writing software is used to inputting projector's control code, then can control various projector with the visualizer.

1. Connect the visualizer to the projector with the RGB, VIDEO cables.
2. Connect the RS232 cable to the computer's connector. The visualizer's


RS232 port is located on its right side.

3. After completion of the connection, turn on the visualizer, click [start] → [All Programs] → Visualizer →  Visualiser Code-Writing and the following dialog box appears as below:



When the indicator of “Current RS-232 Connection Status” is green, that means the connection between the visualizer and the computer’s RS232 connector is good. If the indicator is red, please check if the RS232 cable is connected correctly. When all the cables are connected correctly, please click “Projector” to select your projector model under the drop-down list, then click “Send”. If you can not find your particular projector model in the “Projector”, please do the following:

1). Select “Baud rate” and “parity” and input the projector control code. (The baud rate, parity and control code is supplied by projector’s manufacturer, please refer to the projector’s manual)



The input format of projector’s control code is as follows:

a. If the data is in the numerical value format, please input data directly,


block them off with comma, do not distinguish lowercase and uppercase. For example: the “POWER ON” code in Hitachi projector manual is :


| | | | | | |
|----------|-------|-------|-------|-------|-------|
| BE EF 03 | 06 00 | BA D2 | 01 00 | 00 60 | 01 00 |
|----------|-------|-------|-------|-------|-------|

In the POWRE ON box,Input : be, ef, 03, 06, 00, ba, d2, 01, 00, 00, 60, 01, 00. Then use the same input rule to input other code.

b. If the data is in the character string format, input ‘character string’.

For exampl e: the “POWER ON” code in th e SHARP C40/50 proje ctor manual is :

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| P | O | W | R | - | - | - | 1 |  |
|---|---|---|---|---|---|---|---|---|

(“-” is space,  is enter.)

In the POWER ON box, input 'POWER 1', 0d, 0a

(Remarks: There are 3 spaces after POWER, 0d, 0a is enter.)

Input other codes in the same way.

c. If the data is in the numerical value and character format, then synthesize the above-mentioned formats.

3). Once done, click “Add” to add your projector model, then Click “Send”. Afterward, c lick “Ok”. Now , you can use the visualizer to control your projector.


4. Connect the visualizer’s projector control port to the RS232 port with a RS232 cable (Please disconnect the computer from the RS232 port first) .

Then use buttons on the operation panel to control the projector.


The visualizer provides a 6-pin to 9-pin RS232 cable. If this cable does not match to your projector’s RS232 port, an additional RS232 cable is needed.

This additional RS232 cable can be made based on the pin location of the projector’s RS232 control port. The pin locations of the visualizer are: the pin 1 is RXD (Received Data); the pin 5 is TXD (Transmitted Data); the pin 4 is GND (Ground). Other pins are not defined. The pin location information of the projector is provided by the projector’s manufacturer. The projector’s RS232 control port normally has RXD pin, TXD pin and GND pin, the name may be different. The parallelism of each data pin is shown as follows:

Visualizer's RXD pin-----Projector's TXD pin
 Visualizer's TXD pin-----Projector's RXD pin
 Visualizer's GND pin-----Projector's GND pin



5. If you can not use buttons on the operation panel to control the projector, please use Code-Writing software's projector control code testing function to check if the control code is correct. Click "Projector" button, the following dialog box appears as below:



Connect the visualizer to a computer with a RS232 cable (Please disconnect the projector from the RS232 port first) and select the Baud Rate and Parity based on the projector's Baud Rate, then click the "TEST" button to pop up the Projector Code Test dialog box, input the Baud Rate and Parity based on the projector's Baud rate, then click "Open".




Click the projector control buttons on the visualizer's operating panel to check if the control code that the program received is the same as the sending code. If the receiving code is same to the sending code, the input codes are correct. If the visualizer can not control the projector, please do the following.

1. Check to see if the source control codes of projector are correct.


2. Check to make sure the connection between the visualizer and the projector is correct.

FOLDING THE UNIT

1. **Fold** the right arm light down first onto the base, then the left arm down. **Rotate** the camera head clockwise until the camera head is parallel to the camera stand.




2. Carefully **fold** the camera stand down to the front panel.



Cautions:

- Do not lay the unit down flat.
- Do not try to stand it on its rear or sides.
- Do not try to pick up this unit by pulling the camera stand.



NOT THIS WAY

SPECIFICATIONS

| | |
|---------------------------------|---|
| Resolution | XGA, SXGA, WXGA,720P, 1080P |
| Total Pixels | 2,000,000 |
| Lens | 12 x optical zoom, 10 x electrical zoom |
| Motorized Camera Head | Yes |
| Camera Rotation | Vertically 330° |
| Focus | Auto/manual selectable |
| White balance | Auto |
| Negative/positive conversion | Yes |
| Black/white and color selection | Yes |
| Image/Text mode conversion | Yes |
| Split Image | Yes |
| Image Title | Yes |
| Image Freeze | Yes |
| Image Mirror | Yes |
| Image Rotate | 0° ,90° ,180° ,270° |
| Image Save & Recall | 128 frames saved in fla sh ROM, 4 x 4 multiple screen display |
| Lights | Arm light: 1.5W LED lamps x 2 |
| | Back light: 2.5W LED lamps |
| Input connectors | HDMI (1) |
| | PC Audio (2) |
| | RGB DB15FLC (2) |
| | C Video IN (RCA) (1) |
| | Audio IN (Mini Jack) (1) |
| | MIC IN (phone jack)(1) |
| Output connectors | HDMI (1) |
| | RGB DB15FLC (2) |
| | C Video OUT (RCA) (1) |
| | Audio OUT (Mini Jack) (1) |
| Operating system | Windows XP SP2, Win7 |
| Hardware Requirement | CPU higher than P2.4GHz |

| | |
|-----------------------|--|
| | Memory higher than 256 MB |
| USB connector | 15 frames/sec |
| RS-232 connector | D-Sub, 9-pin, male / 6-pin PS/2 |
| USB port | USB 2.0 |
| Power consumption | 24W |
| Shooting area | 375X280 mm |
| Dimension (W x D x H) | Folded: 510 x 410 x 120mm |
| | Setup: 510 x 530 x 570mm |
| | Packing: 650 x 540 x 230mm |
| Weight | N.W: 5.5Kg (12.1lbs) G.W: 9.5Kg (20.9 lbs) |
| Accessories | AC power cord AC adapter RGB cable HDMI cable Audio/Video cable Computer RS232 cable (9-pin to 9-pin) Projector RS232 cable (6-pin to 9-pin) USB cable Audio convert cable User's manual Software CD Infrared remote control Warranty card |

* Design and specifications are subject to change without prior notice.