



# WIPS2

## Wireless Interactive Presentation Solution

### Introduction



\* Please adopt the USB cable less than 2m length to link TWP-1500 and IWB.



### Quick Installation

WIPS2 stands as Wireless Interactive Presentation Solution. WIPS2 includes a professional wireless presentation system (TWP-1500) and a full-functional interactive portable wireless tablet. By enabling the Revolutionary “interactive” and “UST/UoIP” functions, you can throw your presentations wirelessly from a PC, Mac, iPad, iPhone, or Android devices to a projector, and use the touch screen/IWB, mobile phone or Pad to control the presentation remotely.

### What you might need

- Projector or HDTV with VGA/HDMI interface
- Windows or Mac PC/Laptop
- Apple iPhone, iPad or iPod-touch device
- Android Phone or Tablet device
- Speaker (Optional, for audio projection feature)
- USB Mouse and Keyboard (Optional, for remote desktop feature)
- USB HID Touch Screen/IWB Device (Optional, for UST or IWB over IP feature)

### Hardware Installation

1. Install the antenna
2. Power on the TWP-1500 and press the power button
3. Insert the wireless tablet dongle
4. 

The diagram shows the TWP-1500 connected to a Projector via VGA/HDMI and a wireless tablet dongle.
5. Turn on projector power.
6. It will show the default standby screen as below when system is ready.



7. Attach the speaker cable to TWP-1500 phone jack for audio output

8. After power on the wireless tablet, you may use the pen to control the OSD or launch virtual whiteboard function now.



9. Attach the USB IWB/Touch Screen cable to TWP-1500 rear USB port for UST/IWB remote touch control.

### Software you might need

Software name	Where to get	Description
Wifi-doc (Bundle Version)	Apple store; Google play	High quality presentation via iPhone/iPad or Android devices (Word, Excel, PPT, PDF, Photo, Screenshot)
Mirrorop Receiver	Apple store; Google play	Control the presentation on PC or Mac via iPhone/iPad or Android devices
WIPS2	USB dongle; Access the TWP-1500 Webpage screen. (Default IP is 192.168.100.10)	Project PC/Mac screens to projector or display at once.


\* You can use your mobile or pad to scan the QR code on the OSD screen for accessing APP store or Google Play to download the requested software.



- Virtual Whiteboard without PC



1. Click on the “Whiteboard” button to enable the virtual Whiteboard feature, you can make the free drawing on device screen through wireless Tablet, Mouse, Touch Screen or IWB device.



Home	Click to go back to WIPS2 Standby Screen .
Whiteboard	Click to create a white background page
Blackboard	Click to create a black background page
Red	Red color pen: click cyclically to change the size of pen wide. There are three different type of pen size. 
Green	Green color pen, click cyclically to change the size of pen wide. There are three different type of pen size. 
Blue	Blue color pen, click cyclically to change the size of pen wide. There are three different type of pen size. 
Eraser	Erase part of the pen drawing.
Trash can	Clean the entire pen drawing on the screen.
	Open /Minimize all pen menu bar

- Pen drawing for Screen projection or data sharing







When user are projecting through Windows, Mac, Android and iOS sender application, you can use the Wireless Tablet/Mouse/IWB/Touch Screen to enable the Pen feature and add free drawing on top of projecting screen.

\* You can open all pen menu bar by click button.



Pointer	Change to Pointer mode Smart pointer: Long press for over 1 second, it will Change to Pen Mode automatically. After releasing the finger, it will change back to Pointer mode. And it will clear all annotation first when it start the Smart Pointer.
Pen Mode	Click the button to enable pen drawing function.
Mouse Mode	Click the button to enable mouse mode for remote control function.
Zoom	Click the button to enable 2X magnifier function.
Red Pen	Red color pen: click cyclically to change the size of pen wide. There are three different type of pen size.
Green Pen	Green color pen, click cyclically to change the size of pen wide. There are three different type of pen size.
Blue Pen	Blue color pen, click cyclically to change the size of pen wide. There are three different type of pen size.
Eraser	Erase part of the pen drawing.
Trash can	Clean the entire pen drawing on the screen.
Home	Click to go back to WIPS2 Standby Screen.





	Page Up	Press this button to go to previous page.
	Page Down	Press this button to go to next page.
	Slide Show	Press this button to enable Slide show function of PPT.
	ESC	Press this button to quit Slide show mode .
	Conference Moderator	Click the icon to enable WIPS2 moderator mode Remote control the PC-list and select the device through Wireless tablet/Mouse/Keyboard/ IWB which are connected to TWP-1500
	Whiteboard Mode	Open/Minimize all Pen menu bar.

Software Installation


Download the client software and install on your PC/MAC.  
PC System: Windows 8 / 7/Vista / XP; MAC System: 10.5 - 10.8  
(Ps. You can also launch the application from PnS token directly.)



• PC software installation



• MAC software installation




1. Make sure your PC/MAC WiFi is enabled, and connect your PC/MAC to WIPS2 TWP-1500 box through WiFi.



(PC)

(MAC)

2. Click WIPS2 TWP-1500 icon on desktop to execute the application, or launch the application from PnS token directly.
3. It will start to search WIPS2 TWP-1500 receiver automatically.



4. When it connects to a “Code” protection enabled TWP-1500 receiver, you have to enter the “Code” and press the “Connect” button to login the receiver.  
(You can find the CODE from the right-upper of OSD standby screen)



(PC)



(MAC)